



ARDEX TECHNICAL UPDATE

Update 85

July 18, 2016

To: ARDEX Sales Professionals, Sales Managers, Corporate (select)

From: ARDEX Technical Department

ARDEX UI 720 FLEXBONE – Recommendation Clarification

We are writing to clarify our recommendations for installing ARDEX UI 720 FLEXBONE over adhesive residue.

If the adhesive residue is tacky, spread a polyethylene cleavage membrane or slip sheet (min. 4 mil thickness) over top prior to installing ARDEX UI 720 FLEXBONE. This will prevent the floating membrane from sticking to the adhesive.

Should you have any questions on this information, please contact the ARDEX Technical Service Department.

A handwritten signature in black ink, appearing to read "Tivona Schneider".

Tivona Schneider
Technical Communications Supervisor

ARDEX AMERICAS 400 ARDEX Park Drive Aliquippa PA 15001
P: 724-203-5000 F: 724-203-5001 www.ardexamericas.com