

ARDEX TLT™ Bond Drain Flange

Installation Guide for Mortar Beds

- Install ARDEX TLT™ Building Panels per specific installation instructions.
- Install ARDEX TLT™ Drain Kit per specific installation instructions.
- Adhere the ARDEX TLT™ Bond Drain Flange assembly with ARDEX CA 20 P™.
- Create a level perimeter with ARDEX A 38™ Rapid Set Screed that is 1/4" per foot higher than the bonded drain flange assembly. Every linear foot needs a 1/4" rise, example 3 feet will need 3/4" rise etc.
- Fill in-between the bonded drain flange and the level perimeter with additional ARDEX A 38™. This will then be screeded to create slope to the drain.
- Once allowed to fully cure, cover with the recommended waterproofing membrane, being sure to overlap it onto the bonded drain flange.



tile & stone
Installation Systems

www.ardexamericas.com

BUILT BY
YOU
backed by **ARDEX**