

## ARDEX VR 98™

# Fast-Track, One-Component Moisture Vapor Retarder

Reduces moisture vapor emissions in concrete to acceptable levels for floor coverings

For RH readings up to 98%

For absorbent concrete

No minimum profile required

No priming required

Fast drying - install ARDEX underlayments in as little as 2 hours after applying the second coat

**One-component system** 

Ready for use\*, resealable and reuseable

Easy to use and apply

Water-based

ARDEX Americas 400 Ardex Park Drive Aliquippa, PA 15001 USA Tel: 724-203-5000 Toll Free: 888-512-7339

Fax: 724-203-5001 www.ardexamericas.com

## ARDEX VR 98™

### Fast-Track, One-Component Moisture Vapor Retarder

#### **Description**

ARDEX VR 98™ is a ready-to-use, one-component, water-based, two-coat system formulated to suppress residual moisture in concrete with RH readings up to 98%. ARDEX underlayments may be installed over the second coat in as little as 2 hours without priming. ARDEX VR 98 comes in a ready-to-use, resealable container. It is pigmented blue to help indicate uniform coverage for ease of application.

#### **Moisture Testing**

Prior to beginning the installation, measure the relative humidity within the concrete in accordance with ASTM F2170. When installed in accordance with our written recommendations, ARDEX VR 98 is suitable for moisture levels up to 98% RH. For moisture levels greater than 95% RH, the installation space must be enclosed and acclimated with the HVAC system running, and the ambient humidity must not exceed 60%.

For all installations of ARDEX VR 98, if the slab is on or below grade, an effective and intact vapor retarder must be placed directly below the concrete in conformance with ASTM E1745.

The surface of the concrete must be completely dry at the time the ARDEX VR 98 is installed. Verify concrete surface dryness by mat testing in conformance with ASTM D4263. The test must be conducted for at least 4 hours, which is the time required for ARDEX VR 98 to be set sufficiently. To ensure that condensation does not form, it is extremely important to check the surface temperature of the concrete just prior to installation to verify that this temperature is at least  $5^{\circ}\text{F}$  (3°C) higher than the dew point for the given temperature and humidity in the space and rising. For example, if the dew point temperature in the space is  $60^{\circ}\text{F}$  (16°C), the slab temperature must be  $65^{\circ}\text{F}$  (19°C) or higher and rising.

#### **Substrate Preparation**

All concrete substrates must be structurally sound and solid, surface dry and thoroughly clean and free of all dust, dirt, oil, grease, wax, asphalt, paint, latex compounds, curing and sealing compounds, form release and any contaminant that could act as a bond breaker. In order for the ARDEX VR 98 to obtain a solid bond, the concrete must be clean and absorbent. If necessary, mechanically clean the floor down to sound, solid concrete by shot blasting or similar and mechanically prepare the concrete to ensure the surface is porous. Over-watered, frozen or otherwise weak concrete surfaces also must be cleaned down to sound, solid concrete by mechanical methods. Sanding equipment is not an effective method to remove contaminants from concrete. Acid etching, solvents, sweeping compounds and adhesive removers are not acceptable means of cleaning the substrate. The concrete must also have a minimum tensile strength of 150 psi (10.5 kg/cm<sup>2</sup>) for areas to receive normal foot traffic and 200 psi (14 kg/cm<sup>2</sup>) for areas of heavy commercial traffic when tested in accordance with ASTM C1583.

Substrate and ambient temperatures must be a minimum of 50°F (10°C) for the installation of ARDEX products. Substrates must be dry during installation and cure. If installing over an in-floor heating system, turn the heating system off 48 hours before, during, and at least 48 hours after the installation is complete. Once ARDEX products are installed, the temperature of the floor should not exceed 85°F.

For more detailed information on substrate preparation, please refer to the ARDEX Substrate Preparation Technical Data Sheet at www.ardexamericas.com.

#### **Dormant Cracks and Dormant Saw Cuts**

To achieve continuous moisture vapor suppression, dormant control joints and dormant cracks must be pre-filled with a two-part, low viscosity, 100% solids, rigid crack and joint filler, such as ARDEX ARDIFIX™. Dormant cracks and dormant saw cuts must be filled in strict accordance with the installation instructions provided by the ARDEX Technical Service Department. Once the dormant cracks and dormant saw cuts have been filled properly, broadcast sand to refusal into the fresh material, and allow these areas to cure thoroughly. Remove all excess sand prior to proceeding with the ARDEX VR 98 installation.

#### **Moving Joints and Moving Cracks**

All moving joints and moving cracks must be honored up through the ARDEX VR 98, the ARDEX underlayment and the floor covering by installing a fully flexible sealing compound designed specifically for use in moving joints, such as ARDEX ARDISEAL™ RAPID PLUS.

ARDEX cannot be responsible for issues arising from expansion and isolation joints, saw cuts or new or existing cracks that may develop, widen or become more narrow after the system has been installed.

For questions regarding the appropriateness of specific joint treatment compounds, please contact the ARDEX Technical Service Department at 888-512-7339.

#### **Recommended Tools**

Paint mixing paddle, low speed drill, short-nap paint roller  $^{**}$  and paintbrush

#### **Application**

\*Thoroughly mix ARDEX VR 98 with a low speed drill and paint mixing paddle until the material is evenly distributed throughout the container. **DO NOT ADD WATER OR OTHER ADDITIVES!** Immediately apply the freshly mixed ARDEX VR 98 to the prepared concrete. For best results, pour the ARDEX VR 98 in a serpentine pattern and roll at a 90° angle to the direction of the pour using a short-nap paint roller. \*\*The use of a professional style roller cage is also highly recommended. Roll the material in a uniform direction, without interruption and at a thickness of 8 mils (200 microns). To minimize the potential for pinhole formation, work the ARDEX VR 98 into the surface with the roller to ensure maximum penetration. ARDEX VR 98 can also be worked into the surface with a paintbrush for hard-to-reach areas and corners. Once an area has been coated completely, allow this to dry to a tack-free film for a minimum of 30 minutes (70°F / 21°C).

Once the first coat is dry, apply the second coat at right angles to the first and install without interruption and in a uniform direction at a thickness of 8 mils (200 microns). Allow the second coat to dry to a tack-free film, which will take approximately 2 hours (70°F / 21°C).

**NOTE:** Do not allow more than 24 hours of dry time between coats. If the ARDEX VR 98 was not worked into the surface sufficiently enough to prevent pinholes, you must apply another coat of ARDEX VR 98.

A two-coat installation of 8 mils per coat equates to an application rate of approx. 425 sq. ft. (39 sq. m) per unit, depending on concrete surface profile, texture and porosity.

Allow the final coat of ARDEX VR 98 to completely dry (approx. 2 hours) prior to proceeding.

If an ARDEX Underlayment will be Installed: Install an ARDEX underlayment within 24 hours. Do not exceed an installation thickness of 1/4" (6 mm). Please note that the trowel-applied underlayments approved for use over ARDEX VR 98 are ARDEX FEATHER FINISH®, ARDEX SKM™ and ARDEX GPS™. A trowel without sharp edges, such as a pool trowel, a plastic trowel or a rubber float, must be used to avoid damage to the ARDEX VR 98 during the application of the trowel-applied underlayment.

Please also note that a thin coat of a cementitious material applied over a non-porous surface may not create a porous bonding surface for the finish flooring. For this reason, it will be necessary to consult the flooring manufacturer for confirmation of any minimum thickness requirements for cementitious underlayments as well as for any additional considerations when installing over potentially non-porous surfaces.

If Direct Flooring will be Installed: The following flooring systems may be installed directly over ARDEX VR 98 without the use of an underlayment:

- Floating / non-adhered flooring systems
- Direct-bond, non-wood flooring systems that meet the following criteria:
  - The flooring must be installed with a pressure-sensitive adhesive in a pressure-sensitive application.
  - The pressure-sensitive adhesive must not be solvent based.
  - The pressure-sensitive adhesive must be roller- or spray-applied.
  - The pressure-sensitive adhesive must be suitable for use over non-porous substrates, such as multi-coat, acrylic films on concrete.
  - The pressure-sensitive adhesive must be approved by the manufacturer for direct application over a moisture remediation system.
  - The pressure-sensitive adhesive must not adversely react and/or compromise the ARDEX VR 98.

Please note that the final coat of the ARDEX VR 98 must completely dry (approx. 2 hours; 70°F / 21°C) prior to the installation of the floor covering. Care must be taken not to pierce or otherwise compromise the ARDEX VR 98 during the floor covering installation.

As the ARDEX VR 98-coated concrete will not absorb liquids from the adhesive (water, solvents), an adhesive installed directly over ARDEX VR 98 may need a longer open time than what is listed in the manufacturer's tech data sheet to enable the adhesive to sufficiently dry and to prevent the adhesive's moisture from being trapped between the flooring and the ARDEX VR 98.

Please also note that, under the following circumstances, the flooring cannot be installed directly over the ARDEX VR 98, and, therefore, the appropriate ARDEX underlayment must be installed:

- The adhesive is specified for use over a porous substrate. In this case, it is typically recommended that the underlayment be installed at a minimum thickness of 1/8" (3 mm).
- The surface of the concrete coated with ARDEX VR 98 is not flat and/or smooth enough for the installation of the floor covering.
- The adhesive will be installed with a notched trowel. Use of a notched trowel directly over ARDEX VR 98 has the potential to damage the ARDEX VR 98 and compromise its moisture mitigation capabilities.
- A wet-set adhesive (single- or two-component) will be used. These types of adhesives are not recommended for direct application over ARDEX VR 98.
- Wood flooring will be installed. Wood flooring adhesives are not recommended for direct application over ARDEX VR 98.

If moisture mitigation is required prior to installing an ARDEX topping, use ARDEX MC<sup>™</sup> RAPID One-Coat Moisture Control System for Concrete to Receive ARDEX Products. Refer to the appropriate technical data sheets for further installation instructions.

It is not necessary to re-test the substrate for moisture emissions prior to installing the floor covering.

**NOTE:** Avoid all general traffic over the ARDEX VR 98 surface until the ARDEX VR 98 is completely dry (approx. 2 hours). If the underlayment will not be installed immediately, protect the surface from construction traffic, dirt and debris using Masonite® or similar.

#### **Notes**

FOR PROFESSIONAL USE ONLY.

Clean all tools with water before the ARDEX VR 98 dries.

The installation of ARDEX VR 98 does not require calcium chloride testing of the concrete per ASTM F1869, nor does this ASTM standard permit this test over the top of concrete that has been treated with a moisture remediation system.

Do not apply ARDEX VR 98 if the surface temperature is below  $50^{\circ}$ F ( $10^{\circ}$ C). Store at temperatures between 40 and  $90^{\circ}$ F (5 -  $32^{\circ}$ C). Do not allow to freeze.

Do not reuse container. Dispose of packaging and residue in accordance with federal, state and local waste disposal regulations. Do not flush material down drains.

#### **Precautions**

Carefully read and follow all precautions and warnings on the product label. For complete safety information, please refer to the Safety Data Sheet (SDS) available at www.ardexamericas.com.

### Technical Data According To ARDEX Ouality Standards

All data based on 70°F (21°C) installation temperatures. Physical properties are typical values and not specifications.

**Coverage:** Approx. 425 sq. ft. (39 sq. m) per unit at

2 coats of 8 mils each

Approx. 100 sq. ft. per gal. (2.4 sq. m per L)

at 2 coats of 8 mils each

(Will vary with concrete surface profile,

porosity and texture)

Effect of 14 pH Solution

(ASTM D1308): No effect

Walkable: When completely dry (approx. 2 hours); no max.

provided surface is protected

Install

**Underlayment:** 2 - 24 hours **VOC:** 37.5 g/L

Packaging: One 4.25 gal. (16 L) pail

**Storage:** Store in a cool, dry area. Do not leave containers

exposed to sun. Keep from freezing. Keep away

from heat.

**Shelf Life:** 1 year, if unopened

Open containers remain usable for 6 weeks if sealed and stored under proper conditions. Keep

container closed when not in use.

Warranty: ARDEX Engineered Cements Standard

Limited Warranty applies.

Extended system warranty is available. Please note that training by the ARDEX Technical Service Department is required for extended warranty eligibility. Please contact the ARDEX Technical

Service Department for details.

Made in the USA.

© 2017 ARDEX, L.P. All rights reserved.

Content updated 08-21-2017. Published 08-31-2017. Supersedes all previous versions. Check www.ardexamericas.com for most recent version and for technical updates, which may supersede the information herein.

AT449 (08/17)

Visit www.youtube/ARDEX101 to watch ARDEX Americas product demonstration videos.

For easy-to-use ARDEX Product Calculators and Product Information On the Go, download the ARDEX App at the iTunes Store or Google Play.







ARDEX Americas 400 Ardex Park Drive Aliquippa, PA 15001 USA Tel: 724-203-5000 Toll Free: 888-512-7339

Fax: 724-203-5001 www.ardexamericas.com